Find your perfect fit with our size guide.

All measurements are taken on the sweater itself, not on the body. Lay a sweater that fits you well flat on a table, measure it the same way and compare.

CM

SIZE	XS	S	M	L
BODY LENGTH (cm, front, from neck point)	55.5	57.5	59.5	61.5
CHEST WIDTH (cm, laid flat)	56	58	60	62
SLEEVE LENGTH (cm)	56	58	60	62

HOW TO MEASURE

Body Length

At the front, from the neck point where the collar meets the shoulder, straight down to the hem.

Chest Width

Lay the sweater flat and measure straight across, from armpit to armpit.

Sleeve Length

Along the outside of the sleeve to the end of the cuff.