UNISEX SNOW JACKET

BAYLE-R26

Find your perfect fit with our size guide.

All measurements are taken on the jacket itself, not on the body. Lay a jacket that fits you well flat on a table, measure it the same way and compare.

CM

SIZE	XS	S	M	L	XL	2XL
BODY LENGTH (cm)	74	76	78	80	82	84
CHEST WIDTH (cm, laid flat)	61	63	65	67	69	71
SLEEVE LENGTH (cm, from shoulder seam)	60.5	62	63.5	65	66.5	68

HOW TO MEASURE

Body Length

Centre back, from the collar seam straight down to the hem.

Chest Width

Lay the jacket flat and measure straight across, from armpit to armpit.

Sleeve Length

From the shoulder seam along the outside of the sleeve to the end of the cuff.